




INSTRUCTIONS



A

B



Connect the radio remote control to 9V battery.
Connect the scoreboard to transformer 230/12V DC.
Wait 10 seconds !

8 x NUMBERS


Push and hold „TRANSMISSION“ button.

Switch the button "ON / OFF", on the display is :
0, 000, 00.00

By pressing the „ADJUST“ and „SCORE“ buttons is possible to adjust 0,1,2,3,4,5,6,7,8,9, -, on all positions. The reset to 0, 000, 00.00 is possible by switch ON/OFF. Button „START/STOP“ is not active !

OFF

Push the button „ON/OFF“.



2.

TRANSMISSION

1. 3.

1. PUSH & HOLD TRANSMISSION

2. PUSH SELECTED BUTTON

3. RELEASE TRANSMISSION BUTTON

9V BATTERY

⚠ For better transmission distance lift the remote control higher.

⚠ Scoreboard has 16 different transmission codes. For exchange the transmission code, contact the service center !